


www.colorato.net

# INSTRUCTION MANUAL OF CITRUS JUICER



**MODEL: CLJ-180A** 

Thank you for buying the Citrus Juicer.
Read carefully these Instructions before using the appliance.

### Contents

COLORATO recommends safety first	2
Important safety for your Citrus juicer	2
Important safeguards for all electrical appliances	3
Exploded view of Spare parts	4
Technical Parameters	5
Before use	5
How to operate	5
Cleaning	6
Guarantee of product's good operation	7

#### **COLORATO** recommends safety first

We at COLORATO are very safety conscious. We design and manufacture consumer products with the safety of you, our valued customer foremost in mind. In addition, we ask that you exercise a degree of care when using any electrical appliance and adhere to the following precautions:

#### Important safeguards for your Citrus Juicer

- Carefully read all instructions before operation and save for future reference.
- Remove any packaging material and promotional stickers before using the Citrus juicer for the first time.
- Do not place the Citrus juicer near the edge of a bench or table during operation.
   Ensure that surface is level, clean and free of water, flour etc. Vibration during operation may cause the appliance to move.
- Do not place this appliance on or near a hot gas or electric burner, or where it could touch a heated oven.
- ◆ Always ensure the Citrus juicer is properly assembled before use.
- ◆ Do not leave the Citrus juicer unattended when in use.
- Ensure that the switch in the control panel is in OFF position and then unplug from the power outlet before attaching the Citrus juicer or attempting to move the appliance, or when it is not in use and before cleaning and storing.

- Never place your fingers or utensils inside the Citrus juicer bowl without unplugging the unit from the power outlet.
- Keep hands and utensils out of the bowl while the motor is running, to prevent the possibility of severe personal injury and/ or damage to the Citrus juicer. A rubber scrapper may be used, only when the machine is not running.
- Do not remove Drink mixer's cones from its position whilst in operation. Remove the cone only when the appliance is completely off.
- ◆ To protect against electric shock do not immerse the base, the motor, the plug or the cord in water or any other liquid. Wipe with the damp cloth to clean them.
- Do not use the Citrus juicer for anything other than juicing fruits.
- ♦ Keep the appliance clean.

#### Important safeguards for all electrical appliances

- ♦ Fully unwind the cord before use.
- ◆ To protect against electric shock, do not immerse cord, plug or motor base in water or any other liquid.
- ◆ Do not let the cord hand over the edge of a table or counter, touch hot surfaces or become knotted.
- ◆ This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure they can use the appliance safely.
- Young children should be supervised to ensure that they do not play with the appliance.
- ◆ It is recommended to regularly inspect the appliance. Do not use the appliance if the power supply cord, plug or appliance becomes damaged in any way. Return the entire appliance to the nearest authorized COLORATO Service Centre for examination and / or repair.


- Any maintenance other than cleaning should be performed at a COLORATO authorized Service Centre.
- ◆ This appliance is for professional use. Do not use this appliance for anything other than its intended use. Do not use in moving vehicles or boats. Do not use outdoors.



The symbol on the product means that at the end of its life, the appliance has not to be considered a common waste. It is a special waste and has to be demolished in specific recovery and disposal area, as prescribed by the EC Directive 2002/96/EC(WEEE). By disposing this product correctly, you can avoid negative consequences for the environment and for the human health, due to the presence of potentially dangerous substances in the product.

**Attention** 

## **Exploded view of Spare parts**



#### **Technical Parameters**

Model	CLJ-180A
Power	180 W
Voltage	220V-50Hz
Speed of the motor	1800 r/min
Dimensions	30,8 x 21,8 x 35,4 cm

#### **Before use**

- 1. Read all instructions.
- 2. Check the voltage of your juicer before plugging it in.
- 3. Before plugging in, ensure that the switch is off.

#### How to operate

- 1. Position the cone.
- 2. Cut the fruit that will be squeezed into two halves.
- 3. Switch on the appliance by putting the ON/OFF switch to "1".
- 4. Squeeze the fruit halves.
- 5. Switch off the appliance by putting the ON/OFF switch to "0".

#### Cleaning

- 1. Always switch off the motor and unplug the juicer.
- 2. Never immerse the motor base in water, wipe with a damp cloth to clean it.
- 3. The appliance is very easy to clean by quickly removing all parts that are in contact with the juice: cone, pip filter, bowl etc. Easy to clean removable drip tray.
- 4. Rinse all parts that are coming to contact with the juice immediately after use.
- 5. Take care to wash all parts that are in contact with the juice before using the appliance for the first time.

•

#### **Guarantee of product's good operation**

Hereby the constructor guarantees the good operation of the appliance.

The present guarantee is in effect for 12 months from the date of the purchase of the appliance. The constructor is guaranteeing its good operation and is obliged to repair or replace each defective part that presents constructional imperfection. The cost of the repair and spare parts is coming upon the constructor. The cost of the transportation to the factory, insurances and any other expenses that result from the transport, burden the purchaser despite any particular agreement that is contracted between the purchaser and salesman.

The present guarantee extends only to the original purchaser and its force is ceased when:

The appliance was used for other than its intended use. • Damages were caused from accident, fall, erroneous use etc. • The user or third person attempted to repair the appliance. • The appliance was connected, maintained, used or stored in a way different than the recommended at the book of Instructions-use and maintenance that accompanies it. • A part or a section was modified for any cause. • A part or a dispensable of different origin from that of the factory of manufacture was used. In case that any of the above mentioned is valid, the force of the guarantee of the good operation is ceased and as long as the purchaser is demanding its application, the local Juridical Authority is rendered responsibly.

For the force of the present, it is necessary to be brought or dispatched via registered correspondence to the constructor, the card of acceptance of the terms of the present, signed from the purchaser, in a period of 10 days (stamp of the Post).

If you have a claim under this guarantee, please contact our TECHNICAL SERVICE CENTER. (For faster service, please have model, series and type numbers ready for the operator to assist you). Reasonable proof of the date of the purchase must be presented; otherwise, the effective date of the warranty will be based on the date of manufacture plus ninety days.

COLORATO	ATTENTION: For the force of the guarantee, you should post the present, accompanied from a copy of the Invoice or Retail Sale notice, in a period of 10 days from the date of the purchase, to the following address:  COLORATO • IMPORTS-EXPORTS OF ELECTRICAL AND GAS APPLIANCES.  11, K. MATSI str • 546 36 • THESSALONIKI-GREECE • TEL.+ 30 2310 246808 • FAX: +30 2310 247950  Website: www.colorato.net • e-mail: info@colorato.net		
STAMP OF REPRESENTATIVE			DETAILS OF PURCHASER
			NAME & SURNAME: ADDRESS: Post Code & City: Telephone:
			SIGN
			•••••••••••••••••••••••••••••••••••••••
DATE OF PURCHASE			The undersigned purchaser declares that he was informed of all the terms of the guarantee that are mentioned above and accepts them unconditionally.
Type of the app Serial Number :			IS JUICER CLJ-180A